


Level Control System , (1BK),(1BS),(1BY),(2MA)

From September 2014

**Audi**

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

erWin



Level Control System Control Module


- J197 Level Control System Control Module
- J403 Level Control System Compressor Relay
- J492 All Wheel Drive Control Module
- J533 Data Bus on Board Diagnostic Interface
- J849 Sensor Electronics Control Module
- SF1 Fuse 1 (On Fuse Panel F)
- ST2 Fuse Panel 2
- ST4 Fuse Panel 4
- SF6 Fuse 6 (On Fuse Panel F)
- S110 Self-Leveling Suspension Fuse
- S131 Safety Fuse 1
- T6w 6-Pin Connector
- T9a 9-Pin Connector
- T18a 18-Pin Connector
- T32b 32-Pin Connector

- 51 Ground Connection in Luggage Compartment, Right
- 383 Ground Connection 18 (in Main Wiring Harness)
- 386 Ground Connection 21 (in Main Wiring Harness)
- 387 Ground Connection 22 (in Main Wiring Harness)
- 389 Ground Connection 24 (in Main Wiring Harness)
- B285 Positive Connection 9 (15a) (in Main Wiring Harness)
- B298 Positive Connection 2 (30) (in Main Wiring Harness)
- * Refer to Applicable Wiring Diagram for Fuse Positions
- *2 Avant
- *3 Refer to Applicable Wiring Diagram for Data Bus Networking
- *4 Data Bus Wire (Flexray Bus)

Level Control System Control Module, Adaptive Suspension Valve Block, Left Front Suspension Strut Valve, Left Rear Suspension Strut Valve, Level Control System Compressor Motor

- | | |
|------|---------------------------------------|
| J197 | Level Control System Control Module |
| NX7 | Adaptive Suspension Valve Block |
| N111 | Level Control System Solenoid |
| N148 | Left Front Suspension Strut Valve |
| N149 | Right Front Suspension Strut Valve |
| N150 | Left Rear Suspension Strut Valve |
| N151 | Right Rear Suspension Strut Valve |
| N311 | Level Control Accumulator Valve |
| T2cz | 2-Pin Connector |
| T4ay | 4-Pin Connector |
| T10h | 10-Pin Connector |
| T18a | 18-Pin Connector |
| V66 | Level Control System Compressor Motor |


- | | |
|-----|-------------------------------------------------|
| 51 | Ground Connection in Luggage Compartment, Right |
| 384 | Ground Connection 19 (in Main Wiring Harness) |
| * | Pre-Wired Component |



Level Control Pressure Sensor, Level Control System Control Module, Adaptive Suspension Valve Block

- G291 Level Control Pressure Sensor
- J197 Level Control System Control Module
- NX7 Adaptive Suspension Valve Block
- T10h 10-Pin Connector
- T15a 15-Pin Connector

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink

29 30 31 32 33 34 35 36 37 38 39 40 41 42

Left Rear Level Control System Sensor, Left Front Level Control System Sensor, Level Control System Control Module


- G76 Left Rear Level Control System Sensor
- G77 Right Rear Level Control System Sensor
- G78 Left Front Level Control System Sensor
- G289 Right Front Level Control System Sensor
- J197 Level Control System Control Module
- T4ae 4-Pin Connector
- T4at 4-Pin Connector
- T4av 4-Pin Connector
- T4s 4-Pin Connector
- T15a 15-Pin Connector

B605 Connection 1 (in Interior Wiring Harness)

B606 Connection 2 (in Interior Wiring Harness)

B607 Connection 3 (in Interior Wiring Harness)

* Running Change




- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink

Level Control System Control Module, Left Front Damping Adjustment Valve, Left Rear Damping Adjustment Valve

- J197 Level Control System Control Module
- N336 Left Front Damping Adjustment Valve
- N337 Right Front Damping Adjustment Valve
- N338 Left Rear Damping Adjustment Valve
- N339 Right Rear Damping Adjustment Valve
- T2ab 2-Pin Connector
- T2ba 2-Pin Connector
- T2cb 2-Pin Connector
- T2cr 2-Pin Connector
- T12r 12-Pin Connector

- B571 Connection 38 (in Main Wiring Harness)
- B572 Connection 39 (in Main Wiring Harness)
- B573 Connection 40 (in Main Wiring Harness)
- B613 Connection 41 (in Main Wiring Harness)



- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.